



TO TURN SPOT ON: The power button is on the top left corner of the device, press and hold the button until the power light turns green, when the batteries are low, the light will turn red.

TRACK (boot print): With the power on, press and hold the TRACK button (boot print) until the light above the button blinks green, the GPS light will blink green when the SPOT sees a GPS signal, both the GPS light and the message sending light will blink green when sending your track.

OK (Check in button): With the power on, press and hold the OK button until the light above the button blinks green, the GPS light will blink green when the SPOT sees a GPS signal, both the GPS light and the message sending light will blink green when sending your message.

HELP (hands button): with the power on, open the protective ap, press and hold the HELP button until the light to the left of the button blinks green, the GPS light will blink green when the SPOT sees a GPS signal, both the GPS light and the message sending light will blink green when sending your message.

SOS: ONLY TO BE USED FOR CRITICAL OR LIFE-THREATENING SITUATIONS: with the power on, open the protective ap, press and hold the SOS button until the light to the right of the button blinks green, the GPS light will blink green when the SPOT sees a GPS signal, both the GPS light and the message sending light will blink green when sending your message.